TRICITY BENDIX DISHWASHER BK280 CIRCUIT / SCHEMATIC DIAGRAM



NOTES: AKO 51472 D 16061/0 CAM SWITCH
WIRES TO ON/OFF SWITCH & CAM SWITCH ARE MARKED WITH TAG Nos.
N/O - NORMALLY OPEN CONTACT
N/C - NORMALLY CLOSED CONTACT